

MODEL 616N, 616N-6 & 595 CONVECTION OVEN.
SERVICE KIT No : 00301SK

TOOLS: A: MEDIUM SIZE PHILIP SCREWDRIVER.
B: SMALL SIZE FLAT SCREWDRIVER.
C: CUTTER..

SERVICE PART: 0017743A---- THERMOSTAT.

PROCEDURE:

UNPLUG THE UNIT AND PLACE IT SO IT IS ACCESSIBLE FROM THE FRONT AND RIGHT (ACCESS PANEL)

1.0 THE ACCESS PANEL.

1.1 REMOVE (8) SCREWS HOLDING THE PANEL.

2.0 THERMOSTAT TUBE:

2.1 FROM INSIDE THE OVEN, UNSCREW (2) THUMB SCREWS HOLDING THE BULB GUARD, STRAIGHTEN OUT THE THERMOSTAT TUBE AND PUSS \ PULL THE TUBE THROUGH THE HEAT MODULE, IN TO THE ACCESS CHAMBER.

2.2 CUT (2) PLASTIC THIGH FROM THE WIRES, AND GET THE THERMOSTAT TUBE FREE.

3.0 THERMOSTAT.

3.1 WITH THE SMALL SCREWDRIVER, LOOSEN THE SET SCREW AND THEN REMOVE THE THERMOSTAT KNOB.

3.2 REMOVE (2) SCREWS HOLDING THE THERMOSTAT BODY.

3.3 WITHOUT DISCONNECTING THE EL. WIRES, UNTANGLE THE THERMOSTAT TUBE AND TRANSFER THE TUBE INSULATION ON TO THE REPLACEMENT THERMOSTAT, ALONG WITH THE EL. WIRES, ONE WIRE AT A TIME.

ASSEMBLY OF THE UNIT IS THE REVERSE OF THE DISASSEMBLY.