

17249 (SELCO) THERMOSTAT
INSTALLATION/REPLACEMENT INSTRUCTIONS
FROM (STEMCO) MODEL 101J TO A (SELCO) 098-212R

Model 925W

- 1) UNPLUG UNIT.
- 2) USE A PHILLIPS SCREWDRIVER TO REMOVE THE TOP OF THE UNIT.
- 3) USE A SMALL COMMON SCREWDRIVER TO LOOSEN SET SCREW ON THERMOSTAT KNOB, -REMOVE KNOB.
- 4) REMOVE THERMOSTAT MOUNTING SCREWS.
- 5) PULL THERMOSTAT UP AND REMOVE THE TWO ATTACHED WIRES.
- 6) ATTACH REPLACEMENT THERMOSTAT, (NOTE: CAPILLARY LINE FACES DOWN, ROTATE KNOB FULLY, COUNTER-CLOCKWISE. FLAT OF SHAFT FACING UP.) USE SCREWS FROM STEP (4).
- 7) ATTACH WIRES TO REPLACEMENT THERMOSTAT, (NOTE: WIRES CAN BE ATTACHED TO EITHER TERMINAL.)
- 8) REATTACH THERMOSTAT KNOB, (NOTE: THE SET SCREW MUST BE TIGHTENED DOWN ON THE FLAT OF THE SHAFT.)
- 9) DISCONNECT OLD BULB/CAPILLARY LINE FROM UNIT AND INSTALL REPLACEMENT.
- 10) REATTACH TOP OF UNIT, PLUG UNIT IN AND RESET THERMOSTAT TO ORIGINAL (WORKING) POSITION.