

0017081SK INSTRUCTIONS

REATTACHING MAGNETIC STRIP TO DOOR HANDLE

- 1) REMOVE DOOR FROM UNIT (USE A FLAT SCREWDRIVER) LAY DOOR ON A COUNTER TOP (MAGNET SIDE UP).
- 2) MARK MAGNET LOCATION (EITHER END).
- 3) PEEL MAGNET FROM DOOR.
- 4) LAY ONE FINE BEAD OF ADHESIVE (SUPPLIED WITH THIS SERVICE KIT) DOWN BETWEEN THE TOP AND BOTTOM MARKS AND IN THE CENTER OF THE DOOR FRAME.
- 5) REPOSITION MAGNET BETWEEN TOP AND BOTTOM MARKS.
- 6) USE FILAMENT TAPE TO SECURE MAGNET TO DOOR FRAME (THREE PIECES), WRAP ONE ON EITHER END OF MAGNETIC STRIP, AND ONE IN THE CENTER.
- 7) PRESS MAGNET DOWN FIRMLY.
- 8) FLIP DOOR OVER (MAGNET IS RESTING ON COUNTER).

NOTE: THE MORE DRYING TIME ALLOWED, THE BETTER THE RESULTS (ONE HOUR OR MORE).

WHEN THE ADHESIVE IS DRY AND MAGNET IS SECURE TO THE DOOR, REMOVE TAPE AND REATTACH DOOR TO UNIT.

*THE BOTTLE SUPPLIED WITH THIS SERVICE KIT CONTAINS ENOUGH ADHESIVE TO DO TEN LARGE DOORS, USED SPARINGLY.

FS140021
9-05-97