

17248 (SELCO) THERMOSTAT  
INSTALLATION/REPLACEMENT INSTRUCTIONS

**\*\*SPECIAL NOTE\*\*** THE MOUNTING BRACKETS HAVE BEEN ATTACHED  
90 DEG. OFF FROM SPECIFICATIONS.

\*TO INSTALL PROPERLY, FOLLOW THE STEPS BELOW.

- 1) UNPLUG UNIT.
- 2) USE A PHILLIPS SCREW DRIVER TO REMOVE THE TOP OF THE UNIT.
- 3) USE A SMALL COMMON SCREWDRIVER TO LOOSEN SET SCREW ON THERMOSTAT KNOB, - REMOVE KNOB.
- 4) REMOVE THERMOSTAT MOUNTING SCREWS.
- 5) PULL THERMOSTAT UP AND REMOVE THE TWO ATTACHED WIRES.
- 6) ATTACH WIRES TO RELACEMENT THERMOSTAT.
- 7) CAPILLARY LINE MUST BE FACING UP, FOR PROPER ROTATION.
- 8) REMOUNT THERMOSTAT TO CONTROL PANEL.
- 9) TURN THERMOSTAT SHAFT FULLY COUNTER CLOCKWISE.
- 10) SLIDE KNOB ONTO SHAFT, TURN KNOB (ARROW) TO LOW POSITION. TIGHTEN SET SCREW **FIRMLY**. SET SCREW WILL **NOT** BE CONTACTING FLAT SIDE OF SHAFT.
- 11) DISCONNECT OLD BULB/CAPILLARY FROM UNIT AND INSTALL REPLACEMENT, REATTACH TOP OF UNIT, PLUG UNIT IN, AND RESET THERMOSTAT TO ORIGINAL (WORKING) UNIT.

8-10-98  
FS140027