

**THERMOSTAT KNOBRETROFIT KIT (MODEL 560)**  
**KIT #008241SK**

**TOOLS NEEDED**

Small slotted screw driver

**PARTS INCLUDED**

Knob Part #008242

Dial Part #008241

**INSTALLATION INSTRUCTIONS:**

- 1) Unplug unit from outlet.
- 2) Knob removal: Locate the hole in the side of the thermostat knob. Use the slotted screw driver to loosen the set screw. Remove and discard the thermostat knob and set screw.
- 3) Dial Placement: Remove protective liner from the back of the dial plate. Align dial so the center hole surrounds the thermostat shaft. The other two holes go around the two mounting screws (up & down.) Press dial on firmly (the 0 should be to the right.)
- 4) Knob Installation: align the flat of the knob with the flat on the thermostat shaft. Slide the knob onto the shaft.  
Note: leave 1/8 inch of space between the knob and the dial plate.
- 5) Unit is now ready for operation.