




WISCO INDUSTRIES, INC.

PHONE : 608.835.3106 • TOLL FREE : 800.999.4726 • FAX: 608.835.7399 • www.wiscoind.com

MODEL(S) 561/561A
POWER BOARD REPLACEMENT
0027380SK


DESCRIPTION

This document illustrates how to replace the Power Board for model 561.



TOOLS NEEDED

- #2 Phillips Screwdriver (Stubby Recommended)
- Pliers



PARTS INCLUDED

- (1) 0027380 - Power Board



WISCO INDUSTRIES, INC.


PHONE : 608.835.3106 • TOLL FREE : 800.999.4726 • FAX: 608.835.7399 • www.wiscoind.com

MODEL(S) 561/561A
POWER BOARD REPLACEMENT
0027380SK



UNPLUG UNIT FROM OUTLET AND ALLOW TO COOL

- 1** Remove the grill and clean out tray from the unit. Flip the unit over and remove (8) screws from the bottom panel.



- 2** Remove (3) screws from the rear of the unit. Remove the bottom panel.






WISCO INDUSTRIES, INC.


PHONE : 608.835.3106 • TOLL FREE : 800.999.4726 • FAX: 608.835.7399 • www.wiscoind.com

MODEL(S) 561/561A
POWER BOARD REPLACEMENT
0027380SK

- 3** Remove (4) screws that hold the power board mount to the outer housing of the unit.



- 4** Using the pliers, remove (4) wire clips that are connected to the power board. (**Note:** For convenience during reassembly, mark the location of these wires.)






WISCO INDUSTRIES, INC.

PHONE : 608.835.3106 • TOLL FREE : 800.999.4726 • FAX: 608.835.7399 • www.wiscoind.com

**MODEL(S) 561/561A
POWER BOARD REPLACEMENT
0027380SK**

- 5** Unplug the fan from the board.



- 6** Remove (4) screws that connect the power board to the mount.



- 7** Using the new board, complete all steps in reverse order and you have successfully replaced your units power board. Your unit is now ready for operation.

