

DESCRIPTION

This document illustrates how to replace the Control Board for model 561.





TOOLS NEEDED

- #2 Phillips Screwdriver (Stubby Recommended)
- 11 mm Socket Wrench or Driver

PARTS INCLUDED

- 0027817 Control Board
- 0027818 Temperature Sensor



UNPLUG UNIT FROM OUTLET AND ALLOW TO COOL



Remove the grill and clean out tray from the unit.



2


Pull the control knob off of the faceplate. Using the 11 mm socket wrench or driver, remove the nut holding the control board to the faceplate.







Flip the unit over and remove (8) screws from the bottom panel.






Remove (3) screws from the rear of the unit of the unit and then remove the bottom panel.






6

Remove (4) screws that hold the power board mount to the outer housing of the unit.



6 U a

Unplug the control board from the power board and remove (4) screws holding the control board to the faceplate.





7

Push the control board out of its placement from the faceplate.



8

Unplug the white-coated wire from the board.





9

Using the new board, complete all steps in reverse order and you have successfully replaced your units control board. Your unit is now ready for operation.

